

Lounge Chair

⚠ WARNING

Small parts and sharp points may be present prior to assembly.

Adult assembly required.
For ages 3 and up.

Cleaning:

This unit can be cleaned with a mild soap and water solution. Be sure to wipe all water from the wood surface.


Important:

Do not discard these instructions.
Keep this copy in a safe place.


Assembly Note: To ease assembly, do not fully tighten screws during assembly process. After unit is fully assembled go back and tighten all screws.

HARDWARE

1 = 4




ALLEN KEY (1)




PARTS LIST


A = 1



B = 1



C = 1



ASSEMBLY DIAGRAM

