



## Angry Stool

### **⚠️ WARNING**

Small parts and sharp points may be present prior to assembly.

Adult assembly required.  
For ages 3 and up.

### **Cleaning:**


This unit can be cleaned with a mild soap and water solution. Be sure to wipe all water from the wood surface.

### **Important:**

Do not discard these instructions.  
Keep this copy in a safe place.

**Assembly Note:** To ease assembly, do not fully tighten screws during assembly process. After unit is fully assembled go back and tighten all screws.


### PARTS LIST



**A** = 4



**B** = 4



**C** = 1

### ASSEMBLY DIAGRAM

