



Really Good Stuff® Activity Guide



Book And Binder Holder With Stabilizer Wing

To re-attach your Stabilizer Wing to your Book and Binder Holder:

Step 1.


Find arrows molded into bottom of Stabilizer Wing. Align them (parallel) to each of the bottom sides of the Book and Binder Holder. The pop-up button on the Wing should be corresponding to the hole on the bottom of the Book and Binder Holder.

Arrows molded into bottom of Wing show alignment.



Step 2.

Turn both pieces over while keeping the pop-up button and hole lined up.



Step 3.

Press firmly on either side of the hole at the inside bottom of the Holder and the pop-up button will snap into place.



All activity guides can be found online.