


Rolling Organizer with Magnetic Dry Erase Board Assembly Instructions


Congratulations on your purchase of this **Rolling Organizer with Magnetic Dry Erase Board**.
(Adult assembly required).

This **Really Good Stuff®** product includes:


- A – Center divider
- B – Bottom panel
- C – Dry erase board panel
- D – Right side panel
- E – Left side panel (additional holes for handle)
- F – 10 Shelves
- G – Top panel
- H – Back edge panel (with logo)
- I – Front edge panel
- J – Handle panel
- K – Left side handle panel
- L – Right side handle panel
- M – Handle
- N – 4 Long wood screws
- O – 12 Short rivet nuts with lock washers and machine screws
- P – 36 Long allen screws
- Q – 4 Short wood screws
- R – 1 Wooden peg
- S – 2 Large rivet nuts with bolts (for handle)
- T – 2 Stationary wheels
- U – 2 Casters
- V – 2 Assembly tools



- ① With the channels facing up, attach the center divider **A** to the bottom panel **B**, making sure the edge where there are 2 additional holes on the bottom panel are at the top. Secure with 2 long allen screws **P** through the bottom panel.




- ② Attach the dry erase board panel **C** to the top edge of the bottom panel **B** with 2 long allen screws **P** through the bottom panel.




Rolling Organizer with Magnetic Dry Erase Board Assembly Instructions

- ③ Attach a stationary wheel **T** to the upper left corner of the bottom panel **B** with 2 long wood screws **N** in the two top holes. For the bottom holes, insert 2 short rivet nuts with 2 lock washers **O** through the wheel and bottom panel and then secure with the 2 machine screws **O** from the opposite side of the bottom panel **B**. When secured, make sure both the nut and screw of **O** are tightened.





- ④ Attach a caster **U** to the upper right corner of the bottom panel **B** with the remaining 2 long wood screws **N** in the two top holes. For the bottom holes, insert 2 short rivet nuts with 2 lock washers **O** through the wheel and bottom panel and then secure with the 2 machine screws **O** from the opposite side of the bottom panel **B**. When secured, make sure both the nut and screw of **O** are tightened.




- ⑤ Attach the other caster **U** to the bottom right corner of the bottom panel **B** by inserting 4 short rivet nuts with lock washers **O** through the wheel and bottom panel and then secure with the 4 machine screws **O** from the opposite side of the bottom panel **B**. When secured, make sure both the nut and screw of **O** are tightened. Repeat on the bottom left side with the remaining stationary wheel **T**.

- ⑥ With the channel openings facing up and inward, attach the right side panel **D** to the right side of the dry erase white board panel **C** and the bottom panel **B** of the unit with 6 long allen screws **P**.




Rolling Organizer with Magnetic Dry Erase Board Assembly Instructions

- ⑦ With the channel openings facing up and inward, attach the left side panel **E** to the left side of the dry erase white board panel **C** and the bottom panel **B** of the unit with 6 long allen screws **P**.






- ⑧ Flip the unit over so that the dry erase board side is facing the ground. With the shiny/finished edge of the shelves facing out, place the shelves **F** into the channels, starting on the upper right side, then over and down on the left. We suggest alternating that pattern to allow for the center divider to remain adjustable to easily insert the shelves.



- ⑨ Attach the back edge panel **H** (with the logo) to the long side of the top panel **G** through the bottom of the top panel with 2 short wood screws **Q**. Make sure this is the edge with 3 holes underneath.

- ⑩ Attach the front edge panel **I** to the other long side of the top panel **G** with 2 short wood screws **Q** through the bottom of the top panel.

- ⑪ Place the wooden peg **R** into the center hole of the dry erase white board **C**.



Rolling Organizer with Magnetic Dry Erase Board Assembly Instructions

- ⑫ With the side with logo over the dry erase white board, place the top panel onto the top of the unit. Secure with 2 long allen screws **P** through the top panel. Next, secure with 5 long allen screws **P** in the smaller holes of the left side panel and with 5 long allen screws **P** on the right side panel.

- ⑬ Locate the left side handle panel **K** and with the 3 counter-sunk holes facing out, attach it to the handle panel **J** with 2 long allen screws **P**. Repeat with the right side handle panel **L**.

- ⑭ Slide the rivet nuts **S** through the top holes of the left side of the unit so that the opening faces the outside. Place the assembled handle onto the rivet nuts and secure with the 2 bolts **S** into the rivet nuts. Tighten each end of the nut/bolt. Secure the handle assembly with 2 long allen screws **P** through the inside.

WARNING: Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Always place heaviest items on the bottom shelves.
- Never allow children to climb shelves.

