



Teacher Standing Desk Assembly Instructions

Congratulations on your purchase of this **Teacher Standing Desk**. (Adult assembly required).





This Really Good Stuff® product includes:

A – Top panel	M – 16 Wood pegs
B – Side panel	N – 16 Cam-locks
C – Side panel	O – 16 Cam-lock studs
D – Divider panel	P – 14 Long screws
E – Divider panel	Q – 2 Longest bolts
F – Back panel	R – 4 Longer bolts
G – Bottom panel	S – 5 Shorter bolts
H – Leg	T – 4 Shortest bolts
I – Leg	U – 4 Spring washers
J – Horizontal bar	V – 4 Flat washers
K – 2 Cross bars	W – Black nut
L – 4 Locking wheels	X – Assembly tools

You may also have received a spare part of each piece of hardware.









- 1 Locate the side panel **C**. Screw in 2 cam-lock studs **O** into the back threaded holes. Repeat for the other side panel **B**.
- 2 Locate the back panel **F**. With the 4 small holes facing up, line up the holes on the ends of the back panel with studs on the side panels **B** & **C**. Insert 2 cam-locks **N** into the holes of the back panel on each side and turn to secure.
- 3 Locate the top panel **A**. Place 8 wood pegs **M** into the outer holes of the panel. Screw in 12 cam-lock studs **O** into the outer threaded holes.
- 4 Place assembled frame onto the desktop panel, lining up the holes with the studs and pegs. Insert 8 cam-locks **N** into the bottom holes of the assembled frame and turn to secure.







Teacher Standing Desk Assembly Instructions

- ⑤ With the finished edges facing out and the cam-lock holes facing in, place the divider panels **D** and **E** onto the desk top. Secure with 2 cam-locks **N** into the inner upper holes of each divider and turn to secure.
- ⑥ Place 8 wood pegs **M** into the top larger holes of the assembled frame.
- ⑦ With the logo facing down and counter-edge side up, place the desk bottom **G** onto the unit, lining up the holes with the wood pegs. Secure with 14 long screws **P** into the unthreaded holes.
- ⑧ With the holes for the cross bars facing the back and the hole for the horizontal bar at the back, attach the leg **I** to the bottom panel **G** by lining up the tab holes on the leg with the holes on the bottom panel with 2 shortest bolts **T**. Do not fully tighten yet.
- ⑨ Connect the leg **I** to the side panel **B** from the inside with 2 longer bolts **R** with washers **U** and **V**.
- ⑩ Connect the horizontal bar **J** to the hole at the back of the leg **I** with a longest bolt **Q** from outside. Do not fully tighten yet.



- Check that all bolts are tightened before turning over to use.



Teacher Standing Desk Assembly Instructions

